

Режимы подключения DVR Optimus

| Модель | Режим работы | Аналоговый режим | | Сетевой режим | | | | |
|--|--------------|------------------|----|---------------|------|------|------|----|
| | | 960Н | D1 | 1080P | 960P | 720P | 960Н | D1 |
|  <p>DVR-2004E</p> | 1 | 4 | | | | | | |
| | 2 | | 4 | | | | | |
| | 3 | | 2 | 1 | | 1 | | |
| | 4 | | | | | | | 9 |
| | 5 | | | | | | 8 | |
| | 6 | | | | | 4 | | |
| | 7 | | | 2 | | | | |
| | 8 | | | 1 | | 1 | | 7 |
| | 9 | | | 1 | | 1 | | 2 |